


CLEAR GAME
Oak Desk Clock
CGBW01-BU &
CGBW01-SG:

Features:

- Analog Quartz Time with Seconds Hand
- Alarm
- AA Battery Required (Not Included)
- One Year Limited Warranty



Operating Instructions:

1. **Battery Installation:** Insert one AA battery by matching correct polarity “+” and “-” inside battery compartment. Battery Not Included.
2. **Time:** Turn time knob to adjust to the desired time.
3. **Alarm:** Turn alarm knob to adjust to the desired alarm time.
4. **ON/OFF switch:** Move the switch to the “ON” position to activate the alarm. Move the switch to the “OFF” position to deactivate the alarm.

CLEAR GAME
ONE YEAR LIMITED WARRANTY
IMPORTERS SERVICE CERTIFICATE

CGBW01-BU & CGBW01-SG

Clear Game warranties that it will repair any failure due to defects in materials and/or workmanship free of charge for up to one year from purchase date. **This warranty is by Clear Game, not by the dealer from whom it was purchased.** Clear Game reserves the right to replace any or all inside components in lieu of repair or replace with another similar model of equal value. This warranty does not cover any failure to function properly due to abuse, accidents or misuse. This warranty gives you specific legal rights which may vary from state to state. If your clock needs service, package it carefully and securely in a mailing carton.

Send via prepaid insured Parcel Post to:

Clear Game
C/O DHL Danzas
500 E. Dallas Road
Grapevine, Texas 76051

Please include a brief note explaining the problem. Be sure to print your name and address clearly.

www.cleargameoutdoors.com